


HereLoc wiring schematic -



Note -
 The "brain" controls the relays by grounding the "UP" and "DN" terminals on the terminal strip. Check for relay and motor operation by grounding the "UP" and "DN" terminals.

Gary Thacker, PLLC
www.SurveyTruck.com
 2625 E. 7th St.
 Tucson, AZ 85716
 Cell 520-241-77945
gwthacker@yahoo.com